

Instructions For:

# Flat Base Sign Display




## Product Specifications

Total Graphic Print Size: 22" W x 28" H  
Foot Print Dimensions: 14" W x 10" D

### Product Parts

- 1 - Base
- 2 - Base Screw Holes
- 3 - Poles (x2)
- 4 - Sign Frame
- 5 - Fixed Screws
- 6 - Top Graphic Slit
- 7 - Screws (x2)
- 8 - Hex Wrench




### Step 1

Take all parts out of the box.



### Step 2

Screw the Poles (3) onto the Fixed Screws (5) on the bottom of the Sign Frame (4).




### Step 3

Locate the bevelled side of the Base Screw Holes (2). Feed the Screws (7) through the Base Screw Holes (2) into the Poles (3) and tighten with the Hex Wrench (8). Be sure that the bevelled sides of the Base Screw Holes (2) are facing **away** from the Poles (3) for the head of the Screws (7) to rest flat with the bottom of the base.



### Step 4

Stand the assembled unit upright. Slide the Graphic into the Top Graphic Slit (6) and guide it rest within the bottom of the Sign Frame (4)



### Step 5

Place in desired location.

